
# Whirlpool

## **TOP AND CABINET PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)

AUTOMATIC WASHER



## **TOP AND CABINET PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1	LIT3955899 LIT3955869 LIT3956257	Literature Parts Installation Instructions Feature Sheet Use & Care Guide Energy Guide Wiring Diagram


#### Following May Be Purchased

## DO-IT-YOURSELF REPAIR MANUALS

	LI AIIN IMA	NUALS
	LIT4313896	Manual, Washer Do-It-Yourself
2		Тор
	3955792	White
	3955793	Biscuit
3	62750	Spacer, Cabinet To
		Top (4)
4	357213	Nut, Push-In (2)
5		Cabinet
	63424	White
_	3954357	Biscuit
6	62780	Clip, Top & Cabinet
_	0070040	& Rear Panel (2)
7	3976348	Cabinet –
0	2400644	Sound Damper
8	3400611	Screw, Lid Switch (2)
9	3357011	Screw, 10–16 x 1/2
10	8054939	Seal, Lid
11	8054980	Switch, Lid
13	355274	Screw, Lid Hinge
	000271	Mounting (4)
15	8055257	Hinge, Lid (L.H.)
16	8055256	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	8319539	Bearing, Lid
		Hinge (2)
19		Lid
	3956016	White
	3956017	Biscuit
22	3351614	Screw, Ground
28	3390631	Screw,
0.4	0055700	10–16 x 3/8 (4)
31	3955788	Cover, Dispenser
32	8519517	Dispenser, Bleach

## **CONTROLS AND REAR PANEL PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

## **CONTROLS AND REAR PANEL PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)

			(200.	<b>9</b>	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,			
Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1	3976300	Washer, Water Inlet Hose (4)	15	3952821	Strain Relief, Power Cord	36	3400818	Screw, Timer Mounting
	0.4000=0	(1–1/16 x 5/8)	16		Cap, End (L.H.)	37	8528333	Switch, Rotary
2	3400073	Screw, Ground Hose, Water		8271365 8271368		39	3955803	Panel, Console White
	0040074	Inlet (2)	17	8318201	Clip, Capacitor		3955804	Grey
		Blue Coupler Red Coupler	18	3952164	Valve, Water Mixing		3955805	(Includes #40) Gold
4	9740848	Screw	19		Shield, Capacitor	40		(Includes #40)
5 6		Strap, Console (2) Panel, Rear	20 21		Mini-Buzzer Clamp, Hose	40 44	3955775	Medallion Knob, Timer
7	62747	Pad, Rear Panel	22		Hose, Vacuum			(For LSQ9549LQ2)
8	3951609	Hose, Drain (4 ft.)	23	9724996	Break Clamp, Hose			(For LSQ9549LW2) (For LSQ9549LG2)
	661577	Hose, Drain	24	387606	Break, Vacuum	45		Dial, Timer
		(9 ft.) (Not Included)	25 26		Edge Protector Capacitor,			(For LSQ9549LQ2) (For LSQ9549LW2)
	3357090	Extension Drain Hose	07		Motor Start	46		(For LSQ9549LG2) Clip, Knob (Except
		(21 Inches)	27 28		Clamp, Hose Clamp, Hose	40	0000939	LSQ9549LQ2)
9	3051702	(Not Included.) Timer, Control	29 30		Clip, Harness Clamp, Hose	47	8271339	Knob, Control (For LSQ9549LQ2)
9	3931702	(60 Hz.)	31	8317496	Clamp, Hose		8538957	(For LSQ9549LW2)
		(Motor Not A Service Part)	32	3951449	Hose, Pump To Tub (Includes #30)	49		(For LSQ9549LG2) Screw, 8–18 x 1.25
10		Screw, Ground	33	8055003	Clip, Harness			(Panel to Top)
11 12		Screw 8–18 x 3/8 Switch, Water Level	34	8317975	& Pressure Hose Retainer, Harness	50 51	62863	Screw, 10-16 x 3/8 Cap, End (R.H.)
13	3948608	Bracket, Control	35		Switch, Water		8271359	White
14	661661	Cord, Power (Includes Item 15)			Temperature	58	8271362 3366913	Clamp, Hose
						59 60	8539874	Shield, Suds
						60	3955492	Harness, Wiring (For Detail See Pages 9 & 10)
						61	3357027	Nozzle-Drain Hose
						62	8317940	Drain Hose Assembly

## **AGITATOR, BASKET AND TUB PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold) 23 --8 

## AGITATOR, BASKET AND TUB PARTS For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2

(Designer White)(White/Grey)(Biscuit/Gold)

Illus. No.	Part No.	DESCRIPTION
1 2	63580 358237	Dispenser Screw & Washer (5/16–24 x 1)
3 4 5	3363003 3951632 8528150	Clothes Mover Agitator
6 7	3976308 3354845	Gasket, Tub Ring Clip, Agitator
8 9 10	3355921 3951682 3366877	Washer, Agitator Cam Driven Dog, Agitator
11	3952374	Clutch Bearing-Driven Cam
12 13	21366 8526016	- ·/ -   - · · ·
15 16 17	8519788 63849 389140	Balance Ring Tub
18 19	383727 3347780	Drive
20	3951744	Switch Agitator (Complete)
22 23 24 26	3951608 3354733 3348855 3949550	Spacer, Thrust Cap, Barrier Seal, Inner Cap Washer

#### **MACHINE BASE PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold) 2 23 13 24 25 15 3 2 4 3 Illus. **Part** No. No. **DESCRIPTION** 17 5 1 3400076 Screw, Bracket Mounting 3  $(10-32 \times 5/8)$ 2 64067 Bracket, Spring Outer (2) 3 63907 Spring Suspension,(3) [호취 7 4 3362087 Support & Brake, Tub 18 64065 Bracket, Spring 5 Outer (L.F.) 63466 Link, Leveling (F) 6 Mechanism (2) 6 62597 Spring, Leveling 7 Mechanism 62837 Pin, Knurled 8 62596 Foot, Rear (2) 9 13 3347047 Bearing, Centerpost (2) 14 357409 Seal, Centerpost (3) 15 388492 Spring, Counterweight 62568 Pad, Plate 16 17 3946509 Plate, Suspension (Includes Illus, 16) 26 3363660 Pad, Base 18 3946512 Base Assembly 19 (Includes Illus, 6, 7, 8, 9, 16, 17, 18, & 26) 21 3359452 Nut, Lock (3/8-16)(2)389102 Foot, Front (2) 22 23 356934 Seal, Centerpost (2) 8 21 285203 Centerpost 24 Bearing Kit 22 9 (Includes Illus. 13, 14 & 23) 63134 Ring, Sound 19 25 Deadening 26 63806 Retainer,


Suspension Spring

## BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2

(Designer White)(White/Grey)(Biscuit/Gold)

	(Des	igner wnit	e)(Wnite/Grey)(Biscuit	/Gola)		
<b>©</b>	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	1	388952	Brake & Drive	10	3357334	Screw, Gearcase
			Tube (Complete) (Refer to Page 11	11	62611	To Base (3) Plate, Motor
1	_		For Further Breakdown)		22224	Mount To Gearcase
2	2		Washer, Spin Tube Thrust	12 13		Grommet, Motor (4) Coupling, Motor
3	3		Ring, Spin Tube Support	15	3355454	& Isolation Clip,
	4 5		Ring, Retainer Clutch (Complete)	16	3400516	Anti–Rattle Screw
4	6	3951308	Band & Lining, Clutch (Includes	17 18	3349637	Retainer, Motor (2) Shield, Tub
5	7	62646	Illus. 7 & 8) Cap, Clutch	19		To Motor Motor, Main
	8		Spring (2) Spring, Clutch	20		Drive Switch, Main
	9	3360630	Gearcase (Complete)	21		Drive Motor Retainer, Pump (2)
16			(Refer To Page 12	22	3363394	Pump (Complete)
15			For Further Breakdown)	23 24	3387485	Screw, 10–16 x 5/8 Shield, Motor
9 10 11/12 13 24			-16 17 17 23		20	18 19 21 22 21

WIRING HARNESS PARTS
For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **WIRING HARNESS PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)


Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
1 2 3 4	388498 3347812	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13	3348075	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	23 24 25	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control
5		Clip, Harness	14	3347243	Block, Disconnect	26	3948617	Connector (T.P.A.)
6 7	389379	(Suds Models)	15 16		(Use Term. 352088) Protector Connector			(3-Circuit) (Lid Switch) (Use Term. 3948619
8	352090	Timer, Block Disconnect (White)	17	387566	(2-Way) (Use Term.94614) Plug, Terminal	27	3360056	OR 3948620.) Connector (T.P.A) (3–Circuit)
9	352089	Timer, Block Disconnect (Black)			(4-Way) (Power Cord) (Use M3 Screws)			(Pressure Switch) (Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19	3390423	Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28 29	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Or 94614.) Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	20	3347730 388818	Receptacle (6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)			OR 3948620.)

# FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

## **BRAKE AND DRIVE TUBE PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION				
1	388952	Brake And Drive				
2	62658	Tube (Complete) Ring, Thrust				
2 3 4	91939	Seal, Oil				
4	356427	Seal, Drive Tube				
5	356937	Spacer, Drive				
		Tube				
6	64027	Tube, Basket				
		Drive (Includes				
7	64025	Illus. 3, 4, 5 & 9)				
7 8	64035 64232	Ring, Retaining				
9	62703	Shoe, Brake "T" Bearing,				
9	02703	Spin Tube				
10	62648	Cap, Brake				
. 0	02010	Spring (2)				
11	387806	Spring, Brake				
12	62909	Sleeve, Brake				
		Spring				
13	63023	Cam, Brake				
		Release				
14	63022	Sleeve, Cam				
15	64194	Driver, Brake				
16	90368	Cam Ring, Retaining				
10	90300	King, Ketaliling				
	FOLLOWING PARTS					

## NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


## **GEARCASE PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)

	(Designer Winte)(WinterOrey)(Dis			
	<del></del>		1	
	22			
	$\begin{pmatrix} & & & & & & & & & & & & & & & & & & &$			
12		Illus		DECODIDEION
3		No.	No.	DESCRIPTION
		1	3360630	Gearcase
		0	005000	(Complete)
	23	2	285202 3349985	Cover, Gearcase Seal, Gearcase
		Ü	0010000	Cover
i 'l	7 24	4	285195	Sealer, Gasket
		_	00000	(.20 Fl. Oz.) (6 ml)
8 —	25	5	63320	Pinion, Spin (Includes Illus. 25)
		6	356427	Seal, Spin
¦   9	26			Pinion
10		7	389387	Shaft, Agitator
! 10		8	90369	(Complete) Ring, Retaining (2)
! 9 —		9	62677	Retainer, Spring
11	<u>'</u>	10	62676	Spring, Agitate
		11	63273	Gear, Agitate (Includes 15 and 29)
1 12		12	62619	Washer, Agitate
1 12	<u>'</u>			Gear
13		13	62580	Cam Follower
14 -		14	62581	(Includes 14) Cam, Agitate
		1-7	02001	(Includes 13)
ı ¦		15	285509	Shaft, Agitator
1		16	62618	(Includes 11 and 29) Washer, Cam Thrust
		17	16018	Bearing, Thrust
1 ¦ %		18	85529	Ball, Bearing
		19	389230	Bottom and Pinion,
15 _	_27	21	285352	Gearcase Seal, Thrust Plug
	i (mm)	22	3351614	Screw, Gearcase
				Cover, Mounting (8)
1 16	28	22	2262552	(10–24 x 3/8)
	20	23 24	3362552 285735	Ring, Retaining Washer Kit,
¦ 29 _ ` <b>®</b>		'	200700	Thrust
8		25	62570	Gear, Spin
		26 27	388253 3349296	Neutral Assembly Rack, Connecting
17 =		28	62621	Actuator, Shift
18	19	29	388815	Washer,
				Intermediate
1 0 ° Shimp	man			
21				
1 121				
	4			
I	GC-215-C I			
L				

## **WATER SYSTEM PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain
2	285321	Hose Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

#### **MISCELLANEOUS PARTS**

For Models: LSQ9549LQ2, LSQ9549LW2, LSQ9549LG2 (Designer White)(White/Grey)(Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	Washer, Inlet Hose
		(1-1/16 x 5/8) (4)
3	3366912	Clamp, Hose
4	3359452	Nut, Lock (3/8–16)
5	3366913	Clamp, Hose
6		Foot, Front (2)

## **OPTIONAL PARTS (NOT INCLUDED)**

Illus.	Part

No. No. DESCRIPTION

#### PAINT, TOUCH-UP (1/2oz.)

72017 White 4392899 Biscuit

## PAINT, PRESSURIZED SPRAY (12 oz.)

350938 Primer, Gray 350930 White 4392901 Biscuit

#### Illus. Part No. No. DESCRIPTION

#### PAINT, BULK (1 qt.)

799344 White (Uncut) 4392900 Biscuit (Uncut)

#### OIL

350572 Oil, Gearcase (16 Oz.)

#### **LUBRICANT**

285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)

#### Illus. Part

No. No. DESCRIPTION

#### **SEALER**

285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)

#### **ACCESSORY PARTS**

367031 Drain Protector 285320 Siphon Break Kit